



## **Table of Contents**

---


|  |           |
|--|-----------|
| <b>1. Introduction</b>                 | <b>34</b> |
| 1.1 Use of the manual                  | 35        |
| 1.2 Guarantee terms                    | 35        |
| 1.3 Copyright                          | 35        |
| <b>2. Safety Instructions</b>          | <b>36</b> |
| <b>3. Installation</b>                 | <b>38</b> |
| 3.1 Package content                    | 38        |
| 3.2 Tower configuration setup          | 39        |
| 3.2.1 UPS                              | 39        |
| 3.2.2 UPS + battery cabinet (optional) | 40        |
| 3.3 Rack configuration setup           | 41        |
| 3.4 Rear panel                         | 43        |
| 3.5 Installation procedure             | 44        |
| <b>4. Operation</b>                    | <b>45</b> |
| 4.1 Control Panel                      | 45        |
| 4.1.1 LCD Panel                        | 45        |
| 4.1.2 Display description              | 46        |
| 4.2 Operating modes                    | 47        |
| 4.3 Start-up procedure                 | 48        |
| 4.3.1 Normal mode                      | 48        |
| 4.3.2 Cold start                       | 48        |
| 4.4 Shutdown                           | 49        |
| 4.5 UPS Measurements                   | 49        |
| 4.6 UPS settings                       | 50        |
| 4.7 Settings shortcuts                 | 55        |
| 4.8 Emergency Power Off (EPO)          | 55        |
| 4.9 Communication devices              | 56        |
| <b>5. Troubleshooting</b>              | <b>57</b> |
| <b>6. Warehousing and dismantling</b>  | <b>59</b> |
| 6.1 Warehousing                        | 59        |
| 6.2 Dismantling                        | 59        |

Congratulations on your recent LEGRAND purchase!

## ATTENTION

It is necessary to read the whole manual carefully before doing any operation.  
DAKER DK Plus must be used only in residential, commercial industrial environments.

The following diagram illustrates the architecture of the UPS system:



The major modules consist of:

- An AC-to-DC power converter (rectifier) with PFC control circuit.
- A DC-to-AC high frequency inverter.
- A battery charger.
- A battery bank.
- A DC-to-DC push/pull converter control circuit.
- A static bypass loop.
- Input and output EMI filters.

### 1.1 Use of the manual

This manual must be kept in a safe, dry place and must always be available for consultation.

The manual reflects the state of the art when the equipment was put onto the market. This publication conforms to the standards current on that date; the manual cannot be considered inadequate when new standards come into force or modifications are made to the equipment.

### **INDICATION**

The installation manual is an integral part of the equipment supplied and must therefore be kept for its entire lifetime. In case of need (for example in the case of damage that even partially compromise its consultation) a new copy must be requested from the Manufacturer, quoting the publication code on the cover.

### 1.2 Guarantee terms

The terms of the guarantee may vary depending on the country where the UPS is sold. Check the validity and duration with LEGRAND's local sale representative.

The Manufacturer declines all indirect or direct responsibility arising from:

- failure to observe the installation instructions and use of the equipment which differs from the specifications in the installation manual;
- use by personnel who have not read and thoroughly understood the content of the installation manual;
- use that does not comply with the specific standards used in the country where the equipment is installed;
- modifications made to the equipment, software, functioning logic unless they have been authorized by the Manufacturer in writing;
- repairs that have not been authorized by the LEGRAND Technical Support Service;
- damage caused intentionally, through negligence, by acts of God, natural phenomena, fire or liquid infiltration.

### 1.3 Copyright

The information contained in this manual cannot be disclosed to third parties. Any partial or total duplication of the manual which is not authorized in writing by the Manufacturer, by photocopying or other systems, including by electronic scanning, violates copyright conditions and may lead to prosecution.

LEGRAND reserves the copyright of this publication and prohibits its reproduction wholly or in part without previous written authorisation.

## 2 Safety Instructions

---

This section contains important safety instructions that should always be followed during the installation, use and maintenance of the UPS.

- This product should be installed in compliance with installation rules, preferably by a qualified electrician. Incorrect installation and use can lead to risk of electric shock or fire. Before carrying out the installation, read the instructions and take account of the product's specific mounting location. Do not open up, dismantle, alter or modify the device except where specifically required to do so by the instructions. All Legrand products must be opened and repaired exclusively by personnel trained and approved by Legrand. Any unauthorised opening or repair completely cancels all liabilities and the rights to replacement and guarantees. Use only Legrand brand accessories.
- If any visible damage is found on the product during the unpacking operation, do not install the UPS but repack the unit and return it to your reseller or distributor.
- Before operating the UPS or connecting any load equipment, ensure the UPS is connected to a properly grounded electrical supply.
- The load applied must not exceed the one indicated on the type label of the UPS.
- The ON/OFF button of the UPS does not electrically isolate the internal parts. To isolate the UPS, unplug it from the mains power socket.
- Do not attempt to open or disassemble the UPS; there are no user replaceable parts. Opening the case will void the warranty and introduces the risk of electric shock even when the mains plug is disconnected.
- The mains socket outlet that supplies the UPS shall be installed near the UPS and shall be easily accessible.
- Do not plug non-computer-related items such as medical, life-support and house electric equipments to the UPS output.
- Do not plug laser printers to the UPS output because they have a high start-up current.
- The UPS has its own internal energy source (batteries). If the UPS is switched on when no AC power is available, there is hazardous voltage at the output sockets.



**The batteries inside the UPS are not user-replaceable.** Servicing of batteries must be performed only by electrical hazard authorized personnel.



**CAUTION:** A battery can present a risk of electrical shock and high short circuit current. The following precautions should be observed when working on batteries:

- a) Remove watches, rings or other metal objects.
- b) Use tools with insulated handles.
- c) Wear rubber gloves and boots.
- d) Do not lay tools or metal parts on top of batteries.
- e) Disconnect the charging source prior to connecting or disconnecting battery terminals.
- f) Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electrical shock.

The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).



**CAUTION:** Do not dispose of batteries in a fire. The batteries may explode.



**CAUTION:** Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

- This UPS has dangerous high voltages on its input and output connections. Contact with these voltages may be life threatening.
- In case of emergency, immediately turn off the equipment and disconnect the power cord from the AC power supply to disable the UPS.
- Do not allow any liquid or any foreign object to enter the UPS.
- The UPS is intended for indoor installation in a ventilated, controlled indoor environment with a range of temperature between 0°C (+32°F) and +40°C (+104°F) and non-condensing humidity between 20% and 80%.
- Do not install the UPS in locations with sparks, smoke and hazardous gas or where there is water and excessive humidity. Dusty, corrosive, and salty environments can damage the UPS.
- Do not plug the UPS input into its own output.
- Do not attach a power strip or surge suppressor to the UPS.
- Do not cover the cooling vents and keep a clearance of 20 cm beyond the UPS rear panel. Avoid exposing it to direct sunlight or installing it near heat emitting appliances.
- Unplug the UPS prior to cleaning and do not use liquid or spray detergent.
- Do not place the UPS near equipments that generate strong electromagnetic fields and/or near equipments that are sensible to electromagnetic fields.












### **WARNING**

All the UPSs are category C2 products according to the EN 62040-2. In a residential environment, these equipments may cause radio interference, in which case the user may be required to take additional measures.

#### 3.1 Package content


Check for the following package content:




**3.2 Tower configuration setup**

**3.2.1 UPS**

**Step 1**



**Step 2**






**3.2.2 UPS + battery cabinet (optional)**


**Step 1**

THIS PART COMES FROM THE BATTERY CABINET





**S2**



x8: FROM UPS  
x8: FROM BATTERY CABINET



**Step 2**



THIS PART COMES FROM THE BATTERY CABINET




## 3.3 Rack configuration setup


### INDICATION

For the rack configuration setup it is also possible to use the rack support bracket kit 3 109 52. In this case, follow the instruction sheet contained in the kit.


#### Step 1




#### Step 2




#### Step 3




#### Step 4




**Step 5**



**Step 6**



### 3.4 Rear panel



1. Emergency Power Off (EPO)
2. USB port
3. RS-232 port
4. Cooling fans
5. External battery connector
6. SNMP slot
7. AC input inlet
8. Input circuit breaker
9. Output circuit breakers
10. IEC type F outlets
11. IEC type J outlet


### 3.5 Installation procedure



#### WARNING

Read the safety instructions on chapter 2 before installing the UPS.

1. Position the UPS so that the cooling fans are not obstructed, as visible in the following figure:



2. Connect the IEC input and output cables provided to the appropriate inlet and outlets.
3. Connect the loads to the IEC output cables, ensuring that the switches of the various loads are in the off position.
4. Plug the UPS input cable into a main socket with a suitable voltage and current.
5. Connect the EPO contact in the UPS (normally closed)

## 4 Operation


### 4.1 Control Panel











#### 4.1.1 LCD Panel

























| ITEM | DESCRIPTION   |
|------|---|
| ①    | Display   |
| ②    | The steady green LED indicates that the mains voltage is within the admittable input voltage range                |
| ③ ④  | The green LEDs indicate that the programmable outlets 1 and 2 are activated                                       |
| ⑤    | The green LED blinks if the UPS is in bypass mode.<br>The steady green LED indicates that the UPS is in ECO mode. |
| ⑥    | The steady red LED indicates that there is an alarm   |
| ⑦    | UPS power ON/Silence alarm  |
| ⑧    | UPS power OFF   |
| ⑨    | Special functions access menu   |
| ⑩    | Go to the next screen   |
| ⑪    | Go to the previous screen or change the setting of the UPS  |
| ⑫    | Confirm a changed setting   |

### 4.1.2 Display description



| SIGN  | DESCRIPTION  |
|---|--|
|    | Bypass Fault   |
|    | Utility Input Fault  |
|    | Site wiring Fault  |
|    | Buzzer Silent  |
|    | Overload   |
|   | UPS Service mode<br>(reserved for LEGRAND Technical Support Service) |
|  | Alarm  |
|  | UPS operation diagram  |
|  | 3-Digit Measurement Display  |
|  | Measured item  |
| Fault ←   | Battery fault  |
| Low ←   | Battery low  |
| Testing ←   | Battery test   |

### 4.2 Operating modes


| UPS OPERATING MODE  | LEDs/DISPLAY INDICATION   | BUZZER                 |
|---|---|------------------------|
| <p><b>NORMAL MODE</b><br/>on-line, double conversion</p>  | <p><b>LEDs:</b> steady , , </p> <p style="text-align: center;">LINE — UPS — LOAD</p> <p><b>DISPLAY:</b> </p>  | No sound               |
| <p><b>STORED ENERGY MODE</b><br/>The loads are supplied through the batteries connected to the UPS</p>  | <p><b>LEDs:</b> steady , , </p> <p><b>DISPLAY:</b>  LINE UPS — LOAD </p>                                       | Beep every second      |
| <p><b>BYPASS MODE</b><br/>The loads are supplied directly from the mains. The UPS does not protect the loads. The UPS is in bypass mode after a setting shortcut (paragraph 4.7), a generic alarm or a prolonged overload in normal mode.</p> | <p><b>LEDs:</b> steady , , </p> <p style="text-align: center;">LINE — UPS — LOAD</p> <p><b>DISPLAY:</b> </p>  | Beep every two seconds |
| <p><b>ECO MODE</b><br/>The loads are supplied directly from the mains through the automatic bypass circuit inside the UPS. The output voltage and frequency are the same as the mains.</p>  | <p><b>LEDs:</b> steady , , , </p> <p style="text-align: center;">LINE — UPS — LOAD</p> <p><b>DISPLAY:</b> </p> | No sound               |
| <p><b>CVCF 50/60</b><br/>The UPS maintains constant the output voltage and the output frequency to 50 Hz or 60 Hz according to the setting. With this operating mode it is available only the 75% of the nominal output power.</p>            | <p><b>LEDs:</b> steady , , </p> <p style="text-align: center;">LINE — UPS — LOAD</p> <p><b>DISPLAY:</b> </p>  | No sound               |


See also paragraph 4.6 to set the operating mode.




### 4.3 Start-up procedure


#### 4.3.1 Normal mode

1. Make sure the input breaker is not tripped. If it is, reset it.
2. Plug the UPS input cable into the mains socket.
3. The UPS turns to the standby mode in 5 seconds. The green LED  lights up if the input voltage is within the admittable range and the fans spin. The battery charger is active. In this condition the loads are not powered. The display looks like the following figure:




4. Press  and hold it until the buzzer sounds twice.


The green LEDs   light up. The display looks like the following figure:







5. The start-up procedure is completed. Make sure that the batteries are fully charged or that the UPS has been plugged to the wall receptacle at least for 4 hours before connecting the loads.

#### 4.3.2 Cold start


1. Make sure the internal batteries or the external battery cabinets are connected to the UPS.
2. Press  and hold it until the buzzer sounds twice; then release the key. The display looks like the following figure:



3. Press  again and hold it until the buzzer sounds twice. If the second key confirmation is not completed within 10 seconds, the UPS does not perform the cold start and shuts off.

4. Few seconds after the second key confirmation, the UPS turns on in stored energy mode and the loads are powered. The alarm LED  and the green LEDs   light up. It is audible an intermittent sound alarm.

The display looks like the following figure:






5. The start-up procedure is completed. If the UPS is not plugged to the mains outlet, the loads are powered till the end of the backup time.



### INDICATION

The output frequency is the same that there was at the input before the UPS was shutdown. The default value is 50 Hz but if before the UPS shutdown the input frequency was 60 Hz, then the output frequency after the cold start will be 60 Hz.

### 4.4 Shutdown

1. Press and hold  until the buzzer sounds twice.
2. The UPS stops powering the loads and turns to the standby mode. The green LEDs   switch off. The ventilating fans continue spinning.
3. Unplug the UPS from the wall receptacle if there is still input voltage. After 10 seconds, the fans stop working and the UPS completely shuts down.


### 4.5 UPS Measurements

After the UPS is turned on, it is possible to check the UPS measurements by pressing  or .










The display sequence is:

- AC input voltage and current;
- AC input frequency;
- output voltage;
- output frequency;
- load percentage;
- output current;
- battery voltage;
- battery autonomy;
- UPS internal temperature;
- battery status, real and apparent power.

### 4.6 UPS settings

After the UPS is turned on, it is possible to check the UPS settings by pressing **Function**. The different parameters can be scrolled pressing .

It is possible to change only three parameters while the UPS is supplying the loads. One of these is reserved to the LEGRAND Technical Support Service.

| PARAMETER   | SETTING | DISPLAY   |
|---|---------|---|
| BUZZER  | ON      | <br>Buzzer <b>ON</b>   |
|   | OFF     | <br>Buzzer <b>OFF</b>  |
| QUICK BATTERY TEST  | OFF     | <br>Testing • <b>OFF</b>   |
|   | ON      | <br>Testing • <b>ON</b>  |
| <b>BATTERY STATUS TEST</b><br><br>This function is reserved to the LEGRAND Technical Support Service and must not be activated by the user | OFF     | <br> Battery <b>OFF</b> |
|   | ON      | <br> Battery <b>ON</b>  |

Follow this procedure to change the buzzer setting:








- press the **Function**. The buzzer setting is displayed;
- press **↕** to select ON or OFF;
- confirm the choice by pressing **Function**.

The quick battery test can be performed to check the operation of the batteries. The test must be performed only after the batteries are fully charged, the mains is available and the UPS is powering the loads. Follow this procedure to perform the battery test:

- press **Function**;
- press **↓** to display the battery test setting;
- press **↕** to select ON. The UPS transfers to stored energy mode for 10 seconds. During the test, the loads are always powered with no voltage dip;
- if at the end of the test the UPS transfers back to normal mode without any alarm code, the batteries are working properly.

To change all the other settings, the UPS must be in standby mode. In this condition the loads are not powered, therefore all the needed settings must be performed before turning on the UPS. Follow this procedure to change the UPS settings:







- press simultaneously **ON** and **↓** for approximately three seconds, until the buzzer sounds twice. The LCD displays the first setting indicated in the next table ("buzzer");
- all the different settings can be scrolled pressing **↓**;
- except for the buzzer and the battery test, all the other settings may be changed by pressing **↕**;
- after changing settings, scroll to the "End" screen and then press **Enter** to save all changes;
- the UPS restarts automatically. However, it is also suggested to remove the mains for at least 30 seconds.




| PARAMETER  | SETTING | DISPLAY  |
|--|---------|--|
| <b>BUZZER</b><br><i>(this setting can't be changed with this procedure)</i>  | ON      | <br>Buzzer <b>ON</b>  |
|  | OFF     | <br>Buzzer <b>OFF</b>   |
| <b>QUICK BATTERY TEST</b><br><i>(this setting can't be changed with this procedure)</i>  | OFF     | <br>Testing * <b>OFF</b>  |
| <b>BATTERY STATUS TEST</b><br><i>(this setting can't be changed with this procedure and it is reserved to the LEGRAND Technical Support Service)</i> | OFF     | <br><br>Battery <b>OFF</b> |
| <b>BYPASS VOLTAGE RANGE</b>  | LOW     | <br>Bypass Voltage Window <b>Lo</b>   |
|  | HIGH    | <br>Bypass Voltage Window <b>Hi</b>   |

# DAKER DK Plus

## 1 kVA - 3 kVA

EN

| PARAMETER                                    | SETTING  | DISPLAY   |
|--|--|---|
| <b>BYPASS FREQUENCY RANGE</b>                | If during the normal functioning the bypass frequency goes beyond the setting, the UPS enters in lock mode (alarm and output disconnected) |  <p>The display shows a speaker icon, the word "Bypass", "Frequency Window", and the value "03 Hz".</p> |
| <b>OUTPUT VOLTAGE</b>                        | <b>120 V</b><br><b>208 V</b><br><b>220 V</b><br><b>230 V</b><br><b>240 V</b>   |  <p>The display shows a speaker icon, the word "Inverter Voltage", and the value "220 V".</p>           |
| <b>OPERATING MODE</b><br>(see paragraph 4.2) | <b>NORMAL MODE</b>   |  <p>The display shows a speaker icon, the word "Mode", and the value "Std".</p>                         |
|  | <b>ECO MODE</b>  |  <p>The display shows a speaker icon, the word "Mode", and the value "Eco".</p>                        |
|  | <b>CVCF 50 Hz</b>  |  <p>The display shows a speaker icon, the word "Mode", "Frequency", and the value "50".</p>           |
|  | <b>CVCF 60 Hz</b>  |  <p>The display shows a speaker icon, the word "Mode", "Frequency", and the value "60".</p>           |











| PARAMETER                        | SETTING  | DISPLAY  |
|----------------------------------|--|--|
| <b>OUTPUT VOLTAGE ADJUSTMENT</b> | <p> <b>0 %</b><br/> <b>- 1 %</b><br/> <b>- 2 %</b><br/> <b>- 3 %</b><br/> <b>+ 3 %</b><br/> <b>+ 2 %</b><br/> <b>+ 1 %</b> </p> <p>If during the normal functioning of the UPS the output voltage is slightly below or above the desired value, this setting allows to adjust it</p> |  |
| <b>EXTERNAL BATTERY CABINETS</b> | <p><b>1c - 9c</b></p> <p>Select the number of external battery cabinets connected to the UPS</p>   |  |
| <b>END SCREEN</b>                | <p>Press <b>Enter</b> to save all changes</p>  |  |

### INDICATION

If the UPS is connected to one or more battery cabinets, it is necessary to set their number to forecast a realistic backup time. This can be done from the display of the UPS or by using the software "UPS Setting Tool".

### 4.7 Settings shortcuts


There are two settings shortcuts:

- Bypass Mode: while the UPS is in normal mode (on-line, double conversion) press  and  simultaneously for approximately three seconds, until the buzzer sounds twice. The UPS transfers from normal mode to bypass mode. During this functioning mode, the bypass LED  blinks and the buzzer sounds intermittently. Press again  and  simultaneously until the buzzer sounds twice to return to normal mode.
- Eco Mode: while the UPS is in normal mode (on-line, double conversion) press  and  simultaneously for approximately three seconds, until the buzzer sounds twice. The UPS transfers from normal mode to eco mode. During this functioning mode, the bypass LED  is on. Press again  and  simultaneously until the buzzer sounds twice to return to normal mode.

### 4.8 Emergency Power Off (EPO)

The UPS has an external normally closed contact that can be opened to activate the immediate stop of the UPS. It is possible to connect to each other several EPO contacts of UPS Daker DK Plus to a unique emergency pushbutton.


The EPO terminal is at the back of the UPS and it is needed for the functioning of the UPS.





### 4.9 Communication devices


The UPS has one RS232 serial port, one USB port and one SNMP slot.




Only one communication interface at a time can control the UPS, according to the following priority:

- 1) optional interface card;
- 2) USB;
- 3) RS232.

The following figures show the pinout of the RS232 and USB interfaces:



Pin 3: RS-232 Rx  
Pin 2: RS-232 Tx  
Pin 5: Ground







Pin 1: VCC (+5V)  
Pin 2: D-  
Pin 3: D+  
Pin 4: Ground

It is possible to download some free of charge software from the website <http://www.ups.legrand.com>

The software can be used for the following functions:

- display of all the operations and diagnostic data in case of problems (UPS Communicator);
- setup of special functions (UPS Setting Tool). For instance, the UPS has two programmable outputs for less critical loads. These sockets may be disabled or timed during stored energy mode to ensure the supply of the more critical loads;
- automatic shutdown of the local computer (UPS Communicator).

## 5 Troubleshooting

| INDICATION   | DIAGNOSTIC  | SOLUTION   |
|--|---|--|
| <p>Fault LED </p> <p>Check the error code on the display (see error code table)</p> | <p>Er05, Er39</p>  <p>intermittent sound alarm</p> | <p>The batteries don't work properly. Check for proper battery connection and measure battery voltage to ensure that batteries are charged. Recharge the batteries for 8 hours.</p> <p>If the problem persists or if it is necessary to replace them, contact the LEGRAND Technical Support Service.</p> |
|  | <p>Er12</p>  <p>continuous alarm sound</p>         | <p>Disconnect some non-critical loads from the UPS output until the overload ceases. Check if there is any short-circuit between the output cables due to a faulty insulation. Replace the cables if necessary.</p>  |
|  | <p>Site wiring/Ground fault</p>                    | <p>Check if the power cord is properly plugged, respecting the "L" and "N" wires. If not, re-plug the cord on the socket turning it of 180°. If the power cord is properly plugged, check if the ground-neutral voltage exceeds the limits.</p>  |
|  | <p>Er11, Er14</p> <p>intermittent sound alarm</p>   | <p>Verify that the ventilating fans work properly. If the problem persists or if it necessary to replace them, contact the LEGRAND Technical Support Service.</p>  |
|  | <p>other error codes</p>  | <p>Check the error code table. If the problem persists, contact the LEGRAND Technical Support Service.</p>   |
| <p>The UPS doesn't work in stored energy mode or the backup time is shorter than its intended performance.</p>   | -   | <p>If the backup time remains unsatisfactory after 8 hours of battery charging, contact the LEGRAND Technical Support Service.</p>   |
| <p>The UPS is working normally but the loads are not powered</p>   | -   | <p>Check that all power cords are properly connected. If the problem persists, contact the LEGRAND Technical Support Service.</p>  |

| INDICATION   | DIAGNOSTIC | SOLUTION  |
|--|------------|---|
| The UPS switches into stored energy mode and then back into normal mode when a connected device is turned on or the UPS switches back and forth between the two modes. | -          | A power strip could be connected to the UPS. Do not use it.<br>See also if there is any damage to the utility wall receptacle or if the cord plug is faulty. Replace them if needed.<br>If the problem persists, contact the LEGRAND Technical Support Service. |
| Strange noise or smell   | -          | Shut down immediately the UPS.<br>Disconnect the mains and contact the LEGRAND Technical Support Service.   |
| The UPS switches off after a total discharge of the batteries  | -          | The function of autorestart is enabled by default. When the mains is available, the UPS restarts in normal mode to supply the loads.  |

### Error code table

| ERROR CODE  | MEANING  |
|-------------|--|
| <b>Er05</b> | Battery weak or faulty                                 |
| <b>Er06</b> | Output short-circuit                                   |
| <b>Er07</b> | EPO mode   |
| <b>Er11</b> | UPS over-temperature                                   |
| <b>Er12</b> | Inverter overload                                      |
| <b>Er14</b> | Fans out of order                                      |
| <b>Er28</b> | Bypass overload  |
| <b>Er39</b> | Battery problem during the start-up process of the UPS |

## 6 Warehousing and dismantling

### 6.1 Warehousing

The UPS must be stored in an environment with a room temperature between +20°C (+68°F) and +25°C (+77°F) and humidity less than 90% (not condensing).

The batteries installed inside the UPS are lead/acid sealed and do not require maintenance (VRLA). The batteries should be charged for 12 hours every 3 months by connecting the UPS to the utility supply. Repeat this procedure every two months if the storage ambient temperature is above +25°C (+77°F).



#### CAUTION

The UPS must never be stored if the batteries are partially or totally discharged. LEGRAND is not liable for any damage or bad functioning caused to the UPS by wrong warehousing.

### 6.2 Dismantling



#### DANGER

Dismantling and disposal operations may only be done by a qualified electrician. These instructions are to be considered indicative: in every country there are different regulations with regard to the disposal of electronic or hazardous waste such as batteries. It is necessary to strictly adhere to the standards in force in the country where the equipment is used.

Do not throw any component of the equipment in the ordinary rubbish.



Batteries must be disposed of in a site intended for the recovery of toxic waste. Disposal in the traditional rubbish is not allowed.

Pb Apply to the competent agencies in your countries for the proper procedure.



#### WARNING

A battery may constitute a risk of an electric shock and high short-circuit current. When working on batteries, the prescriptions indicated in chapter 2 are to be adhered to.

It is important to dismantle the various parts the UPS consists of. For these operations, Personal Protective Equipment must be worn.

Sub-divide the components separating the metal from the plastic, from the copper and so on according to the type of selective waste disposal in the country where the equipment is dismantled.

If the dismantled components must be stored before being properly disposed, be careful to keep them in a safe place protected from atmospheric agents to avoid soil and groundwater contamination.

For the disposal of electronic waste it is necessary to refer to the industry standards.



This symbol indicates that in order to prevent any negative effects on the environment and on people, this product should be disposed of separately from other household waste, by taking it to authorised collection centres, in accordance with the EU countries

local waste disposal legislations. Disposing of the product without following local regulations may be punished by law. It is recommended that you check that in your country this product is subject to WEEE legislations.